


4' DISPLAYER PARTS AND SPRAYERS

ITEM #	Description	UNITS			
			6-1945	Repair Kit	6
	Displayer Rack	1	6-7770	Extendable Poly/Brass Wand	6
2209	Poly Sprayer	4	6-7742	18' Brass Wand (2 female ends)	6
1046	Poly Sprayer	12	6-7711	18' Brass Wand	6
2236	Poly Sprayer	12	6-7704	24" Brass Wand	6
6061	Drum Pump	3	6-7734	Crush Proof Wand	12
1949	Tri-poxy Sprayer	6	6-6092	All Weather Hose	6
1449	Tri-poxy Sprayer	12	6-6091	Hose	6
1979	Tri-poxy Sprayer	4	6-6136	42" Hose	6
6-5797	Brass Fan Nozzle	24	3-1813	Drum Pump Hose	2
6-6000	Brass Adjustable Nozzle	24		Header Signs	2
6-6003	Poly Adjustable Nozzle	12		3" x 11" sign	1
1-5941	Brass Fan Nozzle	24		Item Call-Outs	6
1-5943	Brass Fan Nozzle	24		Laminated Charts	4
6-6062	Brass Shut-off	6			
6-4638	Poly Shut-off w/lock	6			
6-4626	Poly Shut-off	6			
6-4636	Poly Shut-off	12			
6-4627	Repair kit	12			
6-1925	Repair kit	12			



2' DISPLAYER PARTS AND SPRAYERS

ITEM #	Description	UNITS			
			6-1945	Repair Kit	6
	Displayer Rack	1	6-7770	Extendable Poly/Brass Wand	6
2209	Poly Sprayer	4	6-7742	18' Brass Wand (2 female ends)	6
1046	Poly Sprayer	12	6-7711	18' Brass Wand	6
2236	Poly Sprayer	12	6-7704	24" Brass Wand	6
6061	Drum Pump	3	6-7734	Crush Proof Wand	12
1949	Tri-poxy Sprayer	6	6-6092	All Weather Hose	6
1449	Tri-poxy Sprayer	12	6-6091	Hose	6
1979	Tri-poxy Sprayer	4	6-6136	42" Hose	6
6-5797	Brass Fan Nozzle	24	3-1813	Drum Pump Hose	2
6-6000	Brass Adjustable Nozzle	24			
6-6003	Poly Adjustable Nozzle	12			
1-5941	Brass Fan Nozzle	24			
1-5943	Brass Fan Nozzle	24			
6-6062	Brass Shut-off	6			
6-4638	Poly Shut-off w/lock	6			
6-4626	Poly Shut-off	6			
6-4636	Poly Shut-off	12			
6-4627	Repair kit	12			
6-1925	Repair kit	12			